

REVOLUTIONARY REVO!

- NOTE -

Device must be activated outdoors.

NO INSTALLATION REQUIRED

- **Tools Included:** Activation Key | Zip Tie | Velcro
- **Location:** Find a place within the vehicle to securely mount your device. This helps avoid the device from shifting.

ACTIVATION IS AS EASY AS 1, 2, 3

- 1 Insert the activation key and hold for 10 seconds.
- 2 Remove the activation key and you will see the LED's turn on and go solid. LED lights will shut off ~10 seconds after activation process.
- 3 Secure in vehicle and go!

NOTE: Activate device outdoors in seconds. Flip card over to see best practices for device placement.



Activation Key



Insert Key

Remove Key,
LED lights
come on



Advantage[®]
Automotive Analytics

PERFORMANCE IS **EVERYTHING!**

BEST PRACTICES FOR OPTIMAL RESULTS

- **Activate Revo outdoors to ensure solid GPS connection.**
- **Make sure device isn't exposed to moisture or extreme heat.**



DEVICE PLACEMENT

Find stable location to hide Revo | Use Velcro and zip-ties to secure | Log-in and confirm location

SUGGESTED LOCATIONS: Remember, every vehicle is different, relocate device if necessary.

Inside side panel



Under center console



Below benchseat



Under dashboard

