

REVOLUTIONARY REVO!

ACTIVATE YOUR
REVO IN SECONDS!

ACTIVATION MADE EASY

- **Tools Included:** Activation Key | Zip Tie | Velcro
- **Location:** Find a place within the vehicle to securely mount your device. This helps avoid the device from shifting.

DEVICE ACTIVATION

- Activate device outdoors.
- Insert the activation key and hold for 10 seconds.
- Remove the activation key and you will see the LED's turn on and go solid. LED lights will shut off ~10 seconds after activation process.
- Be sure the device has a good line of sight to the sky with no metal obstructions above it.



Activation Key



Insert Key

Remove Key,
LED lights
come on



 **advantage**[®]
AutoMatic Analytics

PERFORMANCE IS **EVERYTHING!**

BEST PRACTICES FOR OPTIMAL RESULTS

- Activate Revo outdoors to ensure solid GPS connection.
- Make sure device isn't exposed to moisture or extreme heat.



DEVICE PLACEMENT

Find stable location to hide Revo | Use Velcro and zip-ties to secure | Log-in and confirm location

SUGGESTED LOCATIONS: Note: Every vehicle is different, relocate device if necessary.

Inside side panel



Under center console



Below benchseat



Under dashboard

