

REVO 3.0 ACTIVATION INSTRUCTIONS

No installation required

- **Tools Included:** Activation Key | Zip Ties | Velcro
- **Location:** Find a place in vehicle to securely mount your device. This helps avoid the device from shifting.

Activation is as Easy as 1, 2, 3

- 1 Remove the Yellow Activation Key - LED will illuminate for ~ 30 seconds
- 2 Secure in vehicle and go!
- 3 Login and confirm location



**DEVICE MUST BE
ACTIVATED OUTDOORS!**



Remove Activation Key,
LED lights come on

Best Practices for Optimal Results

- Activate REVO outdoors to ensure solid GPS connection.
- Make sure device is not exposed to high heat areas.

Device Placement

- Find stable location to hide REVO.
- Use Velcro and zip-ties to secure
- Login and confirm location



Under Dashboard



Behind Glove
Compartment



Under Center Console



Below Bench Seat



Every vehicle is different, relocate device if necessary. Be sure the device has good line of sight to the sky with no metal obstructions directly above it.